

MP330 MP3 Firmware Update Procedure


(Please make sure you backup all the data before continuing firmware update procedure.)

Notice:

- a. Before beginning the procedure, please disconnect your MP330 from your computer.
- b. This firmware update program only supports Win2000, WinXP, Win Vista and Win 7. (Please log in with Administrator privileges)
- c. This procedure WILL delete all the files in your mp3 player.
- d. Please DO NOT use any types of USB hubs, including USB ports on your monitor or keyboard.
- e. Please remove any other usb device (excluding: mouse, key board.) on your PC to ensure FW UPGRADE successfully.

Procedure:

1. Before beginning the procedure, please disconnect your MP330 from your computer. **Press and hold the “Reset” button on MP330 for 2 seconds.**



2. Extract the .ZIP file and then double click on the executable file to execute the “MP330: Firmware Upgrade” software program.




3. **Press and hold the “Menu“ button and connect MP330 to an available USB port on a computer.**

4. Click on the “Search Device” button to continue. A “Current Version:XX.XX.XX” message will be displayed in the window indicating that the MP330 has been successfully found. You may release the “Menu“ button now. Click on the "OK" button to begin updating the firmware version of your MP330. This may take a few minutes.



5. After the firmware update process completes, a “Firmware Upgrade Completes...” message will appear. Please click on the “OK” button to close the “MP330: Firmware Upgrade” software program. Congratulations, your MP330 is now updated.



6. Always disconnect the MP330 from a computer by selecting and following the instructions for the “Safely Remove Hardware” icon that can be found on the Windows® Toolbar at the bottom of the computer screen.